


# Test Data Sheet

**PM7-SWIR1\_20**

SN22.1235

**Resonant electro-optic phase modulator**




RF properties	Value	Unit
Resonance frequency: $f_0$ <sup>1)</sup>	5.11	MHz
Bandwidth: $\Delta\nu$	48.8	kHz
Quality Factor: Q	105	
Required RF power for 1rad @ 780nm <sup>2)</sup>	1.0	dBm
max. RF power: $RF_{max}$ <sup>3)</sup>	0.5	W
Optical properties	Value	Unit
Aperture	3x3	mm <sup>2</sup>
Wavefront distortion (633nm)	$\lambda/6$	nm
Recommended optical intensity (780nm)	< 1	W/mm <sup>2</sup>
AR coating ( $R_{avg} < 1\%$ )	630 - 1100	nm


<sup>1)</sup>23°C <sup>2)</sup>with 50Ω termination <sup>3)</sup>no damage with  $RF_{in} < 1W$

# Measured modulation

**Fig. 1: Oscilloscope trace**



**Fig. 2: Carrier/sideband ratio**



**Table 1: Expected modulation**


$\beta = 1 \text{ rad}$	unit	$\lambda_1$	$\lambda_2$
$\lambda$	nm	671	780
P	dBm	5.8	7.4
P	mW	4	5
U	V <sub>p</sub>	0.6	0.7
$U_\pi$	V <sub>p</sub>	2.	2.3
$\beta / U$	rad / V	1.61	1.35

**Fig.1:** Recorded oscilloscope trace retrieved from a test setup as illustrated below.


**Fig.2:** Squared absolute values of first-kind Bessel functions vs. modulation depth. Vertical lines reveal the ratio between the carrier  $|J_0|^2$  and the  $i^{\text{th}}$  sideband  $|J_i|^2$  at a specific  $\beta$ .

**Fig.3:** Dependency between RF amplitude and modulation depth for different wavelengths. Points on the curve allow to retrieve either the required RF amplitude for a specific desired  $\beta$  or the max. achievable modulation depth for a given/available RF power.



**Table 1:** Expected RF-amplitude/-power values and conversion factors for the required wavelength at the reference modulation depth of 1 rad. **Note:** Experimentally recorded modulation depth displayed in Fig.1 might vary from the respective values ( $\beta=1\text{rad}$ ) provided in the table.



**Fig. 3: RF-signal amplitude vs. modulation depth**








## Resonance Characteristics





## Handling instructions

- Input laser polarization must be aligned with respect to the white markers on the housing
- Please handle device carefully. Avoid shock. Don't drop.
- After turn on the resonance frequency might drift slightly with applied RF power. Please compensate by tuning the RF drive frequency until steady-state (~min).

# Package drawing



**Note 2:** crystal aperture is 3x3mm.



Tested by:

Tel: +49 89 2302 9101  
Fax: +49 89 2302 9102  
eMail: [mail@qubig.com](mailto:mail@qubig.com)  
web: [www.qubig.com](http://www.qubig.com)

**Qubig GmbH**  
Balanstr. 57  
81541 Munich  
Germany